

Revised Menu Structure

SCENE

Select & edit SCENEs
Edit PART settings

Scene	Part	Model
●	●	●

Arp Part	Arp Common
----------	------------

41°C/105°F

SCENE
02-10

Night Race

PART 2 ■■■+ ■ OSC □□□□ ⌘ Y ▶

Select
- SCENE with R knob or 1-16
- Bank with L knob or SCENE + 1-16

◀ ▶

← Exit

Enter →

← Exit

Scene Common	Scene Part (offsets)	Scene Zone	Scene Part MFX	Scene Efx Chorus	Scene Efx Delay	Scene Efx Reverb	Scene Efx OD
--------------	----------------------	------------	----------------	------------------	-----------------	------------------	--------------

Scene List

Shift + Enter → SCENE Initialize

PART

Select & edit SCENEs with PART TONE preview
View PART TONE selections
Edit PART settings
Select PART TONEs within current MODEL

Scene	Part	Model
●	●	●

Arp Part	Arp Common
----------	------------

02-10 Night Race

JU058 Soft Subber K

JU050 Crenshaw Ld/Bs K

JX061 Sqr Pluck 1 A

SH034 Fiter Env Bs 1 -

CD061 TR-626 comp A

PART 2 ■■■+ ■ OSC □□□□ ⌘ Y ▶

K = Key Switch on ▲▼ to change line
A = Arp active L / R knob:
- = PART inactive - SCENE line - select SCENE
 - PART line - select TONE within current MODEL

Exit to return to SCENE
Shift + Enter → SCENE Initialize

◀ ▶

← Exit

Enter →

← Exit

Scene Common	Scene Part (offsets)	Scene Zone	Scene Part MFX	Scene Efx Chorus	Scene Efx Delay	Scene Efx Reverb	Scene Efx OD
--------------	----------------------	------------	----------------	------------------	-----------------	------------------	--------------

Current Model Tone List

MODEL BANK

Select PART TONEs (any MODEL)
Edit TONEs


Scene	Part	Model
●	●	●

PART ON:
- 1-5 select PART for edit
- 6-10 PART keyboard on/off

PART OFF:
- 1-16 select MODEL / CATEGORY GROUP

Model JUNO-106

JU050 Crenshaw Ld/Bs



P-LFO ENV

PART 2 ■■■+ ■ OSC □□□□ ⌘ Y ▶

▲▼ to change line
L / R knob:
- Top line - select MODEL, CATEGORY, USER, EXZ
- TONE line - select TONE within active group
Exit to return to SCENE / PART
Shift + Enter → TONE Initialize

◀ ▶

← Exit

Enter →

← Exit

Tone Common	Tone Partial 1	Tone Partial 2	Tone Partial 3	Tone Partial 4	Tone MFX
-------------	----------------	----------------	----------------	----------------	----------

Category & Model Groups 1-16

◀ ▶, 1-16 change group
L / R Knob, ▲▼ move within group

In MODEL BANK pages, ZEN-Core panel edits go to TONE, otherwise to SCENE OFFSETS